

# ALFA / OMEGA Slings

The synthetic fabric materials used in the production of our items have a good resistance to various substances, including some with aggressive properties, providing that they do not remain in contact for a long time.

However, to extend the lifetime of our items, we list herewith some maintenance instructions to apply to the synthetic fabric.

- Avoid extended contact with greasy, oily and/or coloring substances. These substances could be absorbed by the covering material (PVC) causing permanent marks and damaging the structure of the yarn.
- Do not use solvents or detergents made of solvents ( avoid acetone).
- Use water and liquid, non-abrasive detergents, with neutral PH ( $\pm 7$ ), and colorless. If necessary allow the detergent to remain on the fabric surface for some minutes. Rinse generously with water at a temperature not higher than 30° C.
- In case of use of pressure devices (for example high pressure washers), we advise to keep the tip of the lance , at least at a distance of 60/70 cm from the surface of the product. If necessary repeat the procedure rather than have the lance too close.

By following these simple maintenance instructions, you will avoid damaging the surface of our yarn, and a longer life time-result will be guaranteed.