



02STRPCK1412-V1

23/05/2013

Please retain product label and instructions for future reference

Overall Dimensions:

Length = 1391mm
Width = 1178mm
Height = 866mm



BEFORE YOU START PLEASE READ INSTRUCTIONS CAREFULLY

- Check the pack and make sure you have all the parts listed.
- When you are ready to start, make sure you have the right tools at hand (not supplied) including a Phillips screwdriver, Stanley knife, wood saw, step ladder and drill with 2mm bit.
- Ensure there is plenty of space and a clean dry area for assembly.

TIMBER

As with all natural materials, timber can be affected during various weather conditions. For the duration of heavy or extended periods of rain, swelling of the wood panels may occur. Warping of the wood may also occur during excessive dry spells due to an interior moisture loss. Unfortunately, these processes cannot be avoided but can be helped. It is suggested that the outdoor building is sprayed with water during extended periods of warm sunshine and sheltered as much as possible during rain or snow.

Our buildings are delivered pre-treated with a water based timber treatment however this only helps to protect during transit of your garden item. To validate your guarantee and for better protection against weathering it is ESSENTIAL that you treat the garden building with a wood preserver within 3 months of assembly. This will need to be re-applied annually to ensure longevity of your building. Care must be taken when constructing the garden building that it is not touching the ground and is on a suitable base.

BUILDING A BASE

When thinking about where the building and base is going to be constructed: Ensure that there will be access to all sides for maintenance work and annual treatment.

TYPES OF BASE

- Concrete 75mm laid on top of 75mm hard-core.
- Slabs laid on 50mm of sharp sand.

Ensure the base is level and is built on firm ground, to prevent distortion. Refer to diagrams for the base dimensions. The base should be slightly smaller than the external measurement of the building, i.e. The cladding should overlap the base, creating a run off for water. It is also recommended that the floor be at least 25mm above the surrounding ground level to avoid flooding.

Whilst all products manufactured are made to the highest standards of Safety, we cannot accept responsibility for your safety whilst erecting or using this product.

Mercia Garden Products Limited, Sutton On Trent, Newark, Nottinghamshire, NG23 6QN
www.mercia gardenproducts.co.uk

x2

This building should be erected by two adults

2mm Drill bit

For ease of assembly, it is advisable to pilot drill all screw holes and ensure all screw heads are countersunk.



Winter = High Moisture = Expansion
Summer = Low Moisture = Contraction

CAUTION
Every effort has been made during the manufacturing process to eliminate the prospect of splinters on rough surfaces of the timber. You are strongly advised to wear gloves when working with or handling rough sawn timber.

For Assistance Please Contact Customer Care on 01636 880514

Fixing Kit

- 5 1x Door Stop Framing - 28x28x866mm
- 6 1x Door Strip - 12x40x866mm
- 7 1x Side Support Framing - 44x44x489mm




Nail Bag

- 70mm Screw x10
- 50mm Screw x26
- 30mm Screw x20
- 30mm Black Screw x6


Step 1

Remove transportation blocks from the bottom of each panel before beginning assembly. Each Panel should have two blocks.



Step 2


Fix the Front/Back Panel up against the two short tower legs fitting flush to the underneath of the tower. Use 70mm screws to fix through the framing at the top of the panel into the tower base. Using 50mm screws fix the sides of the panel to the tower posts.



Step 3



Fix the large side panel to the front/back panel fitting flush at the top and bottom using 50mm screws. Fix the panel in place from the inside using 3 x 50mm screws into the angled framing.

We advise that you prop the right hand side of the panel up until the unit has been fully constructed.



Step 4


Fix the small side panel the same way as the previous panel, fixing to the back/front panel. Fix the panel in place from the inside using 3 x 50mm screws.



Step 5


Fix the remaining Back/Front panel to the large side panel using 50mm screws. Fix the panel to the base from the underneath using 70mm screws.

We advise that you prop the right hand side of the panel up until the unit has been fully constructed.




Step 6

Fix the door strip to the end of the back/front panel using 30mm screws.




Step 7

Fix the door to the strip using 30mm screws as shown.




Step 8

Fix the door stop frame to the small side panel using 50mm screws.



Step 9

Fix the Side support frame to the base and the back/front panel using 70mm screws. Make sure that the unit is square and the door can open freely before fixing in place.



Step 10

Fix the handle to the door using 30mm black screws, make sure the handle is fitted so that the screws go through into the door framing.

